

An Upward-Looking, Below-Canopy Lidar For Validation of Spaceborne Lidar Products

Alan Strahler, Boston University,
for
David L. B. Jupp
CSIRO Earth Observation Centre
Canberra, ACT, Australia





CSIRO Canopy Lidar Initiative – Research Team

David Jupp	Earth Observation Centre
Darius Culvenor	Forests & Forest Products
Jenny Lovell	Earth Observation Centre
Glenn Newnham	Forests & Forest Products






Ground Based Lidar

- ❖ ECHIDNA™ is ground based lidar technology designed by CSIRO specifically for forest and vegetation assessment
- ❖ CSIRO canopy Lidar Initiative (CLI) has patented ECHIDNA™ and aims to make it operational and commercial in Forestry and Environmental applications
- ❖ The ECHIDNA™ and the current prototype – the ECHIDNA™ Validation Instrument (or “EVI”) has key differences to scanning rangefinders
 - ◆ Digitizes the full ‘waveform’
 - ◆ Has variable beam divergence
 - ◆ Uses full hemispherical scanning
 - ◆ Linear response and calibration



Ground Based Lidar (ECHIDNA™)




A “Real” Echidna – in the forest



EVI (The ECHIDNA™ Validation Instrument)




Principles of Lidar Ranging




EVI data geometry

← Zenith →




EVI provides returned Lidar power from all directions of the hemisphere as a function of time (range) following a laser pulse output with peak power at time t_p .




← Azimuth →




Hard & Soft Returns in EVI Data




Separating components in Plate Carré



Classifications based on Range Moments



ECHIDNA™ Data Projections



Hemispherical





Plate Carré (simple cylindrical)




Horizontal & Radial Slices


MPeg of Hemispherical Scan



Cylindrical projection shows layers of uniform horizontal distance from the instrument




Cut vertical cylinders and
unwrap: constant distance




Slice through cylinders:
constant height

The data can be “sliced” by radial distance
providing tree silhouettes



← Zenith →


Range Moments 18, 20 & 22 (comparison)




← Height →

Range Slice 15-17 m away from and above EVI
for branching, defect and shape of stems

The data can be “sliced” by radial distance providing tree silhouettes




Range Moment




Comparison

← Zenith →




Range Slice 15
for branching, defect and shape of stems



← Height →


and above EVI

The data can be “sliced” by height providing stem plots and horizontal canopy slices



← Zenith →


Range Moments 18, 20 & 22 (for comparison)





← Radius →

Height Slices 0.25, 1.75 & 3.75 m above EVI provide stem information

The data can be “sliced” by height providing stem plots and horizontal canopy slices





Range Moment



Comparison)


← Zenith →




← Radius →

Height Slices 0.25, 1.75 & 3.75 m above EVI provide stem information

Field Data Stem Plot & EVI Stem Plot








EVI



← Radius →

ECHIDNA™ Products – height, LAI & stem location, size distribution, and density





Applications of ECHIDNA™

❖ Primary Information

- ◆ Foliage profile & LAI
- ◆ Stocking, Basal Area & DBH distribution
- ◆ Stem maps and identification
- ◆ Tree silhouettes
- ◆ Bole height & branching

❖ In Progress

- ◆ Stem form factor, taper and sweep (for volume by size class)
- ◆ Separating branches and foliage
- ◆ Allometry from ground to airborne data

❖ The potentials in forestry & ecology are almost unlimited

